




Subsystems for the
UAS intergration into
the airspace

OEM TT-SC1

Data sheet & User manual



Introduction

TT-SC1 is a high quality and low price OEM **ADS-B** receiver series operating at 1090MHz. It is based on the proven **FPGA-In-The-Loop™** technology, which is a unique combination of a multi-core processor and FPGA. The patented solution allows high-speed RF data processing with significantly reduced number of electronic components. Simultaneous miniaturization of the module and its OEM nature open a wide range of possible applications.

The basic version of module offers the possibility of receiving and decoding **ADS-B**. Fast UART interface and easy configuration with AT-commands allows for the simple integration of the module with the user's system. In addition, extra interfaces open the way to customize the firmware and extend the module with non-standard functions. There are several communication interfaces, protocols and special functionalities available on request.

Applications

- SAA / DAA (Sense and Avoid / Detect and Avoid)
- UAS ground stations and high-density traffic surveillance
- UTM / U-Space construction (traffic surveillance network)
- Traffic-flow analysis and statistics
- Monitoring of 1090MHz band (signal integrity check)
- ADS-B/In/Out devices that meet the NextGen/SESAR philosophy

Main features

- Smallest ADS-B implementation on a surface of <math><2\text{cm}^2</math>
- Receiving of ADS-B with RF signal strength/quality analysis
- Up to 100 tracked aircrafts simultaneously
- Multiple supported protocols, i.a. CSV, MAVLink
- High-resolution ADC with real-time signal processing; best-in-class aircraft tracking
- High sensitive front-end, jamming and ESD protection (only version b) with ranges over 150 km (open space, 1dBi antenna)
- Simple module integration via UART interface and AT commands
- Scalable OEM solution with enormous customization potential (additional functions or interfaces on request)
- Firmware update capability (uC and FPGA)
- Designed to meet MOPS defined in TSO-C199

For more information please contact: support@aerobits.pl.

Contents

| | | |
|----------|--|-----------|
| 1 | Technical parameters | 3 |
| 1.1 | Basic technical information | 3 |
| 1.2 | Electrical specification | 3 |
| 1.2.1 | Absolute maximum ratings | 3 |
| 1.2.2 | Recommended operation conditions | 3 |
| 1.2.3 | General electrical parameters | 3 |
| 1.2.4 | Pin definition | 4 |
| 1.3 | Mechanical specification | 6 |
| 1.3.1 | Dimensions | 6 |
| 1.3.2 | Recommended layout | 7 |
| 2 | Principle of operation | 8 |
| 2.1 | States of operation | 8 |
| 2.1.1 | BOOTLOADER state | 8 |
| 2.1.2 | RUN state | 8 |
| 2.1.3 | CONFIGURATION state | 8 |
| 2.2 | Transitions between states | 8 |
| 2.2.1 | BOOTLOADER to RUN transition | 8 |
| 2.2.2 | RUN to CONFIGURATION transition | 9 |
| 2.2.3 | CONFIGURATION to RUN transition | 9 |
| 2.2.4 | CONFIGURATION to BOOTLOADER transition | 9 |
| 3 | UART configuration | 10 |
| 4 | Settings | 11 |
| 4.1 | Write settings | 11 |
| 4.2 | Read settings | 11 |
| 4.3 | Settings description | 11 |
| 4.4 | Errors | 11 |
| 4.5 | Command endings | 11 |
| 4.6 | Uppercase and lowercase | 11 |
| 4.7 | Available settings | 12 |
| 4.8 | Example | 12 |
| 5 | Commands | 13 |
| 5.1 | Commands in BOOTLOADER and CONFIGURATION state | 13 |
| 5.1.1 | AT+LOCK | 13 |
| 5.1.2 | AT+BOOT | 13 |
| 5.2 | Commands in CONFIGURATION state | 13 |
| 5.2.1 | AT+CONFIG | 13 |
| 5.2.2 | AT+SETTINGS? | 13 |
| 5.2.3 | AT+HELP | 13 |
| 5.2.4 | AT+SETTINGS_DEFAULT | 13 |
| 5.2.5 | AT+SERIAL_NUMBER | 14 |
| 5.2.6 | AT+FIRMWARE_VERSION | 14 |
| 5.2.7 | AT+REBOOT | 14 |
| 5.2.8 | AT+REBOOT_BOOTLOADER | 14 |
| 5.3 | Commands in RUN state | 14 |
| 6 | Protocols | 15 |
| 6.1 | CSV protocol (AERO) | 15 |
| 6.1.1 | CRC | 15 |
| 6.1.2 | ADS-B Aircraft message | 15 |
| 6.1.3 | Statistics message | 17 |
| 6.2 | MAVLink protocol | 18 |
| 6.2.1 | ADS-B Aircraft message | 18 |

1 Technical parameters

1.1 Basic technical information

| Parameter | Description | Min. | Typ. | Max. | Unit |
|-------------------------|---|------|--------|------|------|
| Carrier frequency ADS-B | | - | 1090 | - | MHz |
| RX sensitivity ADS-B | Operation at 50 Ohm U.fl connector (OEM version b) | - | -85 | - | dBm |
| AERO (baud) | AT commands | - | 115200 | - | bps |
| Antenna connector | RF-IPX125-1G-AU (version b only) | - | - | - | - |

Table 1: General technical parameters.

1.2 Electrical specification

1.2.1 Absolute maximum ratings

| Parameter | Min. | Max. | Unit |
|----------------------|------|-----------|------|
| Storage temperature | -5 | +40 | °C |
| Supply voltage (VCC) | 2.7 | 3.6 | DCV |
| Other pin voltage | -0.4 | VCC + 0.4 | DCV |
| RF input ADS-B | - | +10 | dBm |

Table 2: Absolute maximum ratings.

1.2.2 Recommended operation conditions

| Parameter | Min. | Max. | Unit |
|-----------------------|------|------|------|
| Operation temperature | -30 | +85 | °C |
| Supply voltage (VCC) | 3.0 | 3.6 | DCV |

Table 3: Recommended operation conditions.

NOTE: In some cases cooler required – please contact support@aerobits.pl

1.2.3 General electrical parameters

| Parameter | Description | Min. | Typ. | Max. | Unit |
|---------------------|--|-----------|------|-----------|------|
| Current consumption | | - | 70 | - | mA |
| Input Low Voltage | RESET, UARTs, CAN, USB, SPI, I2C | -0.3 | - | 0.8 | DCV |
| Input High Voltage | RESET, UARTs, CAN, USB, SPI, I2C, GPIO | VCC - 0.7 | - | VCC + 0.3 | DCV |
| Output Low Voltage | UARTs, CAN, USB, I2C, SPI, GPIO | - | - | 0.4 | DCV |
| Output High Voltage | UARTs, CAN, USB, I2C, SPI, GPIO | VCC - 0.4 | - | - | DCV |

Table 4: General electrical parameters.

1.2.4 Pin definition

Pin arrangement of OEM TT-SC1 is shown on the figure below (1).

| Pin number | Pin Name | Pin Type | Description |
|--------------|----------|----------------|---|
| 1 | VCC1 | Power | 3.3V (digital supply) |
| 2 | TX1 | CMOS Output | UART1 data output |
| 3 | RX1 | CMOS Input | UART1 data input |
| 4 | TX0 | CMOS Output | UART0 data output |
| 5 | RX0 | CMOS Input | UART0 data input |
| 6 | GND | GND | Common ground |
| 7 | () | N/A | No commercial use (keep floating) |
| 8 | GND | GND | Common ground |
| 9 | CS | CMOS Output | Serial Peripheral Interface Chip select |
| 10 | MISO | CMOS Input | Serial Peripheral Interface Data input |
| 11 | MOSI | CMOS Output | Serial Peripheral Interface Data output |
| 12 | SCK | CMOS Output | Serial Peripheral Interface Clock |
| 13 | GND | GND | Common ground |
| 14 | GND | GND | Common ground |
| 15 version a | RF_IN | RF Input | RF Input (antenna) |
| 15 version b | GND | GND | Common ground |
| 16 | GND | GND | Common ground |
| 17 | I/O | CMOS Output | LED Output (digital) |
| 18 | PPS | CMOS Input | 1PPS GNSS signal |
| 19 | GND | GND | Common ground |
| 20 | B/C | CMOS Input | Bootloader / Configuration mode |
| 21 | I2C_SDA | Bi-directional | I2C Data line |
| 22 | I2C_SCL | Bi-directional | I2C Clock line |
| 23 | VBUS | Power | USB Power line |
| 24 | DP | Bi-directional | USB+ |
| 25 | DM | Bi-directional | USB- |
| 26 | RESET | CMOS Input | Reset input / active low |

Table 5: Pin definitions of OEM TT-SC1.

NOTE: The pins which are grayed-out in table above (e.g. I2C, SPI, CAN interfaces) are not used in standard design and are reserved for custom firmware implementations.




Figure 1: Pin arrangement of OEM TT-SC1.

1.3 Mechanical specification

1.3.1 Dimensions




Figure 2: Mechanical drawing of OEM TT-SC1

| Symbol | Min. (mm) | Typ. (mm) | Max. (mm) |
|-------------------|-----------|-----------|-----------|
| Aa (version a) | 15.9 | 16.0 | 16.1 |
| Ab (version b) | 19.9 | 20.0 | 20.1 |
| B | 12.9 | 13.0 | 13.1 |
| C | 2.3 | 2.40 | 2.5 |
| D | 0.9 | 1.0 | 1.1 |
| E | 0.9 | 1.0 | 1.1 |
| F | 2.9 | 3.0 | 3.1 |
| H | 0.6 | 0.7 | 0.8 |
| J | 0.4 | 0.5 | 0.6 |
| K | 0.6 | 0.7 | 0.8 |
| L | 0.7 | 0.8 | 0.9 |

Table 6: Dimensions and tolerances.

1.3.2 Recommended layout




Figure 3: Footprint of OEM TT-SC1

NOTE: In case of OEM version A the RF inputs indicated in the footprint(3) should be matched to 50ohm.

2 Principle of operation

During work module goes through multiple states. In each state operation of the module is different. Each state and each transition is described in paragraphs below.




Figure 4: State machine of OEM TT-SC1

2.1 States of operation

2.1.1 BOOTLOADER state

This is an initial state of OEM TT-SC1 after restart. Firmware update is possible here. Typically module transits automatically to RUN state. It is possible to lock module in this state (prevent transition to RUN state) using one of BOOTLOADER triggers. UART baud is constant and is set to 115200bps. After powering up module, it stays in this state for up to 3 seconds. If no BOOTLOADER trigger is present, module will transit to RUN state. Firmware upgrade is possible using Micro ADS-B App software. For automated firmware upgrading scenarios, aerobits_updater software is available. To acquire this program please contact: support@aerobits.pl.

2.1.2 RUN state

In this state module is working and receiving the data from aircrafts. It uses selected protocol to transmit received and decoded data to the host system. In this state of operation module settings are loaded from non-volatile internal memory, including main UART interface's baud.

2.1.3 CONFIGURATION state

In this mode change of stored settings is possible. Operation of the module is stopped and baud is set to fixed 115200bps. Change of settings is done by using AT-commands. Changes to settings are stored in non-volatile memory on exiting this state. Additional set of commands is also available in this state, allowing to e.g. reboot module into BOOTLOADER state, check serial number and firmware version. It is possible to lock module in this state (similarly to BOOTLOADER) using suitable command.

2.2 Transitions between states

For each of state transitions, different conditions must be met, which are described below. Generally, the only stable state is RUN. Module always tends to transit into this state. Moving to other states requires host to take some action.

2.2.1 BOOTLOADER to RUN transition

BOOTLOADER state is semi-stable: the module requires additional action to stay in BOOTLOADER state. The transition to RUN state will occur automatically after short period of time if no action will be taken. To prevent transition from BOOTLOADER state, one of following actions must be processed:

- Pull BOOT/CONFIG pin low during start of module
- Send `AT+LOCK=1` command while device is in BOOTLOADER state (always after power on for up to 3s)
- Send `AT+REBOOT_BOOTLOADER` command in CONFIGURATION state. This will move to BOOTLOADER state and will lock module in this state.

If none of above conditions are met, the module will try to transit into RUN state. Firstly it will check firmware integrity. When firmware integrity is confirmed, module will transit into RUN state, if not, it will stay in BOOTLOADER state.

To transit into RUN state:

- Release or pull high BOOT/CONFIG pin
- If module is locked, send `AT+LOCK=0` command

When module enters RUN mode it will send `AT+RUN_START` command.

2.2.2 RUN to CONFIGURATION transition

To transit from RUN into CONFIGURATION state, host should do one of the following:

- Pull BOOT/CONFIG pin low
- Send `AT+CONFIG=1` (using current baud). This method is not recommended, because module will support multiple protocols in future and Aerobits Sp. z o.o. cannot ensure that this command will be present in all protocols.

When module leaves RUN state it sends `AT+RUN_END` message, then `AT+CONFIG_START` message on entering CONFIGURATION state. The former is sent using baud from settings, the latter always uses 115200bps baud.

2.2.3 CONFIGURATION to RUN transition

To transit from CONFIGURATION into RUN state, host should do one of the following:

- Release or pull high BOOT/CONFIG pin
- Send `AT+CONFIG=0` command.

When module leaves CONFIGURATION state it sends `AT+CONFIG_END` message, then `AT+RUN_START` message on entering RUN state. The former is always sent using 115200bps baud, the latter uses baud from settings.

2.2.4 CONFIGURATION to BOOTLOADER transition

To transit from CONFIGURATION into BOOTLOADER state, host should do one of the following:

- Send `AT+REBOOT_BOOTLOADER` command.
- Send `AT+REBOOT` and when module enters BOOTLOADER state, prevent transition to RUN state.

When entering the bootloader state, the module sends `AT+BOOTLOADER_START`.

3 UART configuration

Communication between module and host device is done using UART interface.

In CONFIGURATION and BOOTLOADER state transmission baud is fixed at 115200bps.

The UART interface uses settings as described in table 7.

| UART Settings | | | | |
|------------------|------|--------|-----|------|
| Parameter | Min. | Typ. | Max | Unit |
| Baud | - | 115200 | - | bps |
| Stop Bits Number | - | 1 | - | - |
| Flow Control | - | None | - | - |
| Parity Bit | - | None | - | - |

Table 7: UART settings.

4 Settings

In RUN state, operation of the module is determined based on stored settings. Settings can be changed in CONFIGURATION state using AT-commands. Settings can be written and read.

NOTE: New values of settings are saved in non-volatile memory when transitioning from CONFIGURATION to RUN state.

Settings are restored from non-volatile memory during transition from BOOT do RUN state. If settings become corrupted due to memory fault, power loss during save, or any other kind of failure, the settings restoration will fail, loading default values and displaying the AT+ERROR (Settings missing, loaded default) message as a result. This behavior will occur for each device boot until new settings are written by the user.

4.1 Write settings

After writing a new valid value to a setting, an AT+OK response is always sent.

```
AT+SETTING=VALUE
For example AT+PROTOCOL=1
Response: AT+OK
```

4.2 Read settings

```
AT+SETTING?
For example: AT+PROTOCOL?
Response: AT+PROTOCOL=1
```

4.3 Settings description

```
AT+SETTING=?
For example: AT+PROTOCOL=?
Response:
```

```
Setting: PROTOCOL
  Description: Selected protocol (0: NONE, 2: CSV, 3: MAVLINK)
  Type: Integer decimal
  Range (min.): 0
  Range (max.): 5
  Is preserved: 1
  Is restart needed: 0
```

4.4 Errors

Errors are reported using following structure:

```
AT+ERROR (DESCRIPTION)
DESCRIPTION is optional and contains information about error.
```

4.5 Command endings

Every command must be ended with one of the following character sequences: “\n”, “\r” or “\r\n”. Commands without suitable ending will be ignored.

4.6 Uppercase and lowercase

All characters (except preceding AT+) used in command can be both uppercase and lowercase, so following commands are equal:

AT+PROTOCOL?

AT+pRoToCoL?

NOTE: This statement is true in configuration state, not in bootloader state. in bootloader state all letters must be uppercase.

4.7 Available settings

| Setting | Min | Max | Def | Comment |
|-------------|-----|-----|-----|---|
| PROTOCOL | 0 | 6 | 2 | Selected protocol. Not all values are valid for all devices. 0 - None 2 - CSV (AERO) 3 - MAVLink |
| SUBPROTOCOL | 0 | 0 | 0 | Reserved for future use |
| | | | | |

Table 8: Settings

4.8 Example

As an example, to switch OEM TT-SC1 module to CSV protocol, one should send following commands. “<<” indicates command sent to module, “>>” is a response.

```
<< AT+CONFIG=1\r\n
>> AT+OK\r\n
<< AT+PROTOCOL=2\r\n
>> AT+OK\r\n
>> AT+OK\r\n
<< AT+CONFIG=0\r\n
```

5 Commands

Apart from settings, module supports set of additional commands. Format of this commands are similar to those used for settings, but they do not affect operation of module in RUN state.

5.1 Commands in BOOTLOADER and CONFIGURATION state

5.1.1 AT+LOCK

AT+LOCK=1 - Set lock to enforce staying in BOOTLOADER or CONFIGURATION state

AT+LOCK=0 - Remove lock

AT+LOCK? - Check if lock is set

5.1.2 AT+BOOT

AT+BOOT? - Check if module is in BOOTLOADER state

Response:

AT+BOOT=0 - module in CONFIGURATION state

AT+BOOT=1 - module in BOOTLOADER state

5.2 Commands in CONFIGURATION state

5.2.1 AT+CONFIG

AT+CONFIG=0 - Transition to RUN state.

AT+CONFIG? - Check if module is in CONFIGURATION state.

Response:

AT+CONFIG=0 - module in RUN state

AT+CONFIG=1 - module in CONFIGURATION state

5.2.2 AT+SETTINGS?

AT+SETTINGS? - List all settings. Example output:

AT+PROTOCOL=1

AT+SUBPROTOCOL=0

5.2.3 AT+HELP

AT+HELP - Show all settings and commands with descriptions. Example output:

SETTINGS:

AT+PROTOCOL=2 [Selected protocol (0: NONE, 2: CSV, 3: MAVLINK)]

AT+SUBPROTOCOL=0 [Subprotocol of selected protocol]

COMMANDS:

AT+HELP [Show this help]

AT+TEST [Responds "AT+OK"]

AT+SETTINGS_DEFAULT [Load default settings]

AT+REBOOT [Reboot system]

5.2.4 AT+SETTINGS_DEFAULT

AT+SETTINGS_DEFAULT - Set all settings to their default value.

5.2.5 AT+SERIAL_NUMBER

AT+SERIAL_NUMBER? - Read serial number of module.

Response:

```
AT+SERIAL_NUMBER=07-0001337
```

5.2.6 AT+FIRMWARE_VERSION

AT+FIRMWARE_VERSION? - Read firmware version of module.

Response:

```
AT+FIRMWARE_VERSION=10101017(May 11 2018)
```

5.2.7 AT+REBOOT

AT+REBOOT - Restart module.

5.2.8 AT+REBOOT_BOOTLOADER

AT+REBOOT_BOOTLOADER - Restart module to BOOTLOADER state.

NOTE: This command also sets lock.

5.3 Commands in RUN state

AT+CONFIG=1 - transition to CONFIGURATION state.

NOTE: This command also sets lock.

6 Protocols

6.1 CSV protocol (AERO)

CSV protocol is simple text protocol, that allows fast integration and analysis of tracked aircrafts. CSV messages start with '#' character and ends with "\r\n" characters. There are following types of messages:

1. ADS-B Aircraft message,
2. Statistics message.

NOTE: In future versions, additional comma-separated fields may be introduced to any CSV protocol message, just before CRC field, which is guaranteed to be at the end of message. All prior fields are guaranteed to remain in same order.

6.1.1 CRC

Each CSV message includes CRC value for consistency check. CRC value is calculated using standard CRC16 algorithm and its value is based on every character in frame starting from '#' to last comma ',' (excluding last comma). After calculation, value is appended to frame using hexadecimal coding. Example function for calculating CRC is shown below.

```
uint16_t crc16(const uint8_t* data_p, uint32_t length){
    uint8_t x;
    uint16_t crc = 0xFFFF;
    while (length--){
        x = crc>>8 ^ *data_p++;
        x ^= x>>4;
        crc = (crc<<8) ^ ((uint16_t)(x<<12)) ^ ((uint16_t)(x<<5)) ^ ((uint16_t)x);
    }
    return swap16(crc);
}
```

6.1.2 ADS-B Aircraft message

This message describes state vector of aircraft determined from ADS-B messages and is sent once per second. The message format is as follows:

```
#A:ICAO,FLAGS,CALL,SQ,LAT,LON,ALT_BARO,TRACK,
VELH,VELV,SIGS,SIGQ,FPS,NICNAC,ALT_GEO,ECAT,CRC\r\n
```


| #A | Aircraft message start indicator | Example value |
|----------|---|---------------|
| ICAO | ICAO number of aircraft (3 bytes) | 3C65AC |
| FLAGS | Flags bitfield, see table 10 | 1 |
| CALL | Callsign of aircraft | N61ZP |
| SQ | SQUAWK of aircraft | 7232 |
| LAT | Latitude, in degrees | 57.57634 |
| LON | Longitude, in degrees | 17.59554 |
| ALT_BARO | Barometric altitude, in feet | 5000 |
| TRACK | Track of aircraft, in degrees [0,360) | 35 |
| VELH | Horizontal velocity of aircraft, in knots | 464 |
| VELV | Vertical velocity of aircraft, in ft/min | -1344 |
| SIGS | Signal strength, in mV | 840 |
| SIGQ | Signal quality, in mV | 72 |
| FPS | Number of raw MODE-S frames received from aircraft during last second | 5 |
| NICNAC | NIC/NAC bitfield, see table 11 (v2.6.0+) | 31B |
| ALT_GEO | Geometric altitude, in feet (v2.6.0+) | 5000 |
| ECAT | Emitter category, see table 12 (v2.7.0+) | 14 |
| CRC | CRC16 (described in CRC section) | 2D3E |

Table 9: Descriptions of ADS-B message fields.

| Value | Flag name | Description |
|--------|----------------------------|---|
| 0x0001 | PLANE_ON_THE_GROUND | The aircraft is on the ground |
| 0x0002 | PLANE_IS_MILITARY | The aircraft is military object |
| 0x0100 | PLANE_UPDATE_ALTITUDE_BARO | During last second, barometric altitude of this aircraft was updated |
| 0x0200 | PLANE_UPDATE_POSITION | During last second, position (LAT & LON) of this aircraft was updated |
| 0x0400 | PLANE_UPDATE_TRACK | During last second, track of this aircraft was updated |
| 0x0800 | PLANE_UPDATE_VELO_H | During last second, horizontal velocity of this aircraft was updated |
| 0x1000 | PLANE_UPDATE_VELO_V | During last second, vertical velocity of this aircraft was updated |
| 0x2000 | PLANE_UPDATE_ALTITUDE_GEO | During last second, geometric altitude of this aircraft was updated |

Table 10: ADS-B message Flags description.

The NIC/NAC bitfield is transmitted in big endian hexadecimal format without leading zeros. Table 11 describes its bitfield layout. The meaning of NIC/NAC indicators is exactly the same as described in ED-102A.

| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
|----------|----|----|----|------------------|----|---|---|------------------|---|---|---------------------|-----|---|---|---|
| Reserved | | | | NAC _p | | | | NAC _v | | | NIC _{baro} | NIC | | | |

Table 11: Structure of NIC/NAC bitfield in CSV protocol.

Below is a list of emitter category values returned in ECAT field.

| ECAT value | Description |
|------------|---|
| 0 | Unknown. |
| 1 | Light (below 15500 lbs.). |
| 2 | Small (15500 - 75000 lbs.). |
| 3 | Large (75000 - 300000 lbs.). |
| 4 | High-Vortex Large (aircraft such as B-757). |
| 5 | Heavy (above 300000 lbs.). |
| 6 | High performance (above 5g acceleration and above 400 knots). |
| 7 | Rotorcraft. |
| 8 | Reserved. |
| 9 | Glider, Sailplane. |
| 10 | Lighter-Than-Air. |
| 11 | Parachutist, Skydiver. |
| 12 | Ultralight, hang-glider, paraglider. |
| 13 | Reserved. |
| 14 | Unmanned Aerial Vehicle. |
| 15 | Space, Trans-atmospheric Vehicle. |
| 16 | Reserved. |
| 17 | Surface Vehicle - Emergency Vehicle. |
| 18 | Surface Vehicle - Service Vehicle. |
| 19 | Point Obstacle (includes Tethered Ballons). |
| 20 | Cluster obstacle. |
| 21 | Line obstacle. |

Table 12: ADS-B emitter category values in CSV protocol.

If data of any field of frame is not available, then it is transmitted as empty. For example:

```
#A:4CA948,300,,2122,52.99750,13.76526,37000,169,442,0,814,72,3,,6F1C\r\n
#A:424313,,,2362,52.43431,14.84535,37000,65,456,0,806,61,0,,6843\r\n
```

NOTE: SIGS and SIGQ fields are updated based on raw MODE-S frames. They are calculated from frames received in last second. If there were no receiver frames (FPS=0), those fields will not be updated.

NOTE: SIGS is measured based on analog RF signal. This signal has DC offset of about 700mV.

6.1.3 Statistics message

This message contains some useful statistics about operation of module. Format of that frame is shown below:

```
#S:CPU,RES,RES,FPSS,RES,RES,CRC
```

| #S | Statistics message start indicator | Example |
|------|---|---------|
| CPU | CPU load in % | 12.1 |
| RES | Reserved for future use | - |
| RES | Reserved for future use | - |
| FPSS | Number of MODE-S frames received in last second | 3 |
| RES | Reserved for future use | - |
| RES | Reserved for future use | - |
| CRC | CRC16 (described in CRC section) | 2D3E |

Table 13: Statistics message fields.

6.2 MAVLink protocol

OEM TT-SC1 can be switched to use MAVLink protocol. This can be achieved by altering PROTOCOL setting. When MAVLink protocol is used, module is sending list of aircrafts every second. MAVLink messages have standardized format, which is well described on official protocol webpage (mavlink.io/en/messages).

6.2.1 ADS-B Aircraft message

Aircrafts are encoded using ADSB_VEHICLE message (mavlink.io/en/messages/common.html#ADSB_VEHICLE). MAVLink message contains several data fields which are described below.

| Field Name | Type | Description |
|---------------|----------|--|
| ICAO_address | uint32_t | ICAO address |
| lat | int32_t | Latitude, expressed as degrees * 1E7 |
| lon | int32_t | Longitude, expressed as degrees * 1E7 |
| altitude | int32_t | Barometric/Geometric Altitude (ASL), in millimeters |
| heading | uint16_t | Course over ground in centidegrees |
| hor_velocity | uint16_t | The horizontal velocity in centimeters/second |
| ver_velocity | uint16_t | The vertical velocity in centimeters/second, positive is up |
| flags | uint16_t | Flags to indicate various statuses including valid data fields |
| squawk | uint16_t | Squawk code |
| altitude_type | uint8_t | Type from ADSB_ALTITUDE_TYPE enum |
| callsign | char[9] | The callsign, 8 chars + NULL |
| emitter_type | uint8_t | Type from ADSB_EMITTER_TYPE enum |
| tslc | uint8_t | Time since last communication in seconds |

Table 14: MAVLink ADSB_VEHICLE message description

The ADS-B vehicle may transmit barometric, as well as geometric altitude. The SUBPROTOCOL setting allows for toggling altitude transmit priority:

- When set to 0, altitude field will be filled with geometric altitude first. If not available, barometric altitude will be used.
- When set to 1, barometric altitude will be preferred.

Please read carefully

Information contained in this document is provided solely in connection with Aerobits products. Aerobits reserves the right to make changes, corrections, modifications or improvements to this document, and to products and services described herein at any time, without notice. All Aerobits products are sold pursuant to our own terms and conditions of sale. Buyers are solely responsible for the choice, selection and use of the Aerobits products and services described herein, and Aerobits assumes no liability whatsoever, related to the choice, selection or use of Aerobits products and services described herein. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services, it shall not be deemed a license granted by Aerobits for use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering use, in any manner whatsoever, of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN AEROBITS TERMS AND CONDITIONS OF SALE, AEROBITS DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO USE AND/OR SALE OF AEROBITS PRODUCTS INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT. UNLESS EXPRESSLY APPROVED IN WRITING BY AN AUTHORIZED AEROBITS REPRESENTATIVE, AEROBITS PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE.

Information in this document supersedes and replaces all previously supplied information.

© 2023 Aerobits - All rights reserved