Aerobits

Subsystems for the
UAS integration into the airspace

Plane Map 2

Data sheet - User manual



Contents

1 Introduction **3**
1.1 Features 3

2 Installation **4**
2.1 Installation on Windows 4
2.1.1 Option 1 5
2.1.2 Option 2 8
2.2 Installation on Linux 10

3 Quick start **11**
3.1 Filtering options 12
3.2 Configuration file 13
3.3 Command line 13

4 Disclaimer **14**

This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

1 Introduction

PlaneMap 2 is application designed to visualize received data in CSV and JSON protocol. It enables visualization of air traffic around the installed receiver.

1.1 Features

- **Quick start with the products of AEROBITS company**
- **Easy air-traffic visualization**
- **Cross platform**
- **Data visualization fom serial or TCP/IP connected device**
- **Simple module integration via USB or UART interface and AT commands**
- **Aircraft flight parameters preview**
- **Messages payload preview**

For more information please contact support@aerobits.pl.

This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

2 Installation

2.1 Installation on Windows

Run the unzip **planemap_v2_windows-v1.x.x.zip** file and go into this folder.



Now there are two options.

This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

2.1.1 Option 1

Type cmd into path and hit enter.



This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

Type in cmd **PLANEMAP_V2.exe** with device port number and hit enter.



This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

We got running instance, go to linked address **http://127.0.0.1:8001/** into the browser.



This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

2.1.2 Option 2

We can create *bat* or *ps1* files to run application by one click. Create txt file and paste this into:

```
@echo off
start "Aerobits PLANEMAP_V2" cmd /k "cd /d C:\path\to\project1 && PLANEMAP_V2.exe␣
↪COM49"
```

Now change file extension from *txt* into *bat* and click this file.



This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

Or create *ps1* file:

```
Start-Process powershell -ArgumentList "-NoExit", "-Command", "cd 'C:\path\to\
↪project1'; ./PLANEMAP_V2.exe COM49"
```

Now change file extension from *txt* into *ps1*, right click this file and run in PowerShell.



This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

2.2 Installation on Linux

Unzip planemap_v2_linux-v1.x.x.zip file and go into this folder. Run application by typing:

```
./PLANEMAP_V2 /dev/ttyUSB0
```





This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

3 Quick start

Application can visualize data from Aerobits serial device or TCP/IP data in two formats **CSV** and **JSON**. We can visualize multiple systems such as:

- ADS-B
- UAT
- FLARM
- RemoteID

Table 1: Icons description.

ICON	Description
	ADS-B
	UAT
	FLARM
	RemoteID
	Drone Operator

All input data can be logged into the file.

Warning:

The user can log all input data to the debug.log file only on the main computer with running instance of the **PLANEMAP_V2**.

This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

3.1 Filtering options

The user can turn on or turn off visible systems on the map:





This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

3.2 Configuration file

The PLANEMAP_V2 has special configuration file in **yaml** format for fast startup and customization. Using this file user can connect multiple sources to application, such as:

- serial device
- TCP/IP device
- subscribe MQTT topics

There is no limit for number of sources, PLANEMAP_V2 can parse data in **CSV** or **JSON** formats.

1. To use this feature create **config.yaml** alongside app and paste your own configuration:

```
- broker: "broker.address.com" # GS2L/trkME
  port: 1889
  username: "user"
  password: "password"
  topics:
  - "BROKER/TOPICS"
  websocket: true
  tls: true
- ip: "192.168.1.199" # DRS-1A/F/U/R
  port: 2000
- port: "/dev/ttyUSB0" # Eval TT-SC1/TT-SF2/TT-SU2
  baudrate: 115200
```

2. Save file and run PLANEMAP_V2 app with *config.yaml* as argument.

3.3 Command line

The PLANEMAP_V2 can be run in command line with a few parameters. Just simply run app in command line to print available parameters:

```
./PLANEMAP_V2

Add serial port name as one argument for serial connection.
Default baudrate is 115200 but it can be changed with -b option.
   ./PLANEMAP_V2.exe COM3
   ./PLANEMAP_V2.exe COM3 -b 3000000

Add IP and port as two arguments for TCP connection.
   ./PLANEMAP_V2.exe 192.168.1.10 2000

Add .yaml or .yml file name with connection configuration as one argument.
For mqtt connection.
   ./PLANEMAP_V2.exe config.yaml
```


This document is subject to change without notice. For technical questions, contact: support@aerobits.pl

4 Disclaimer

Information contained in this document is provided solely in connection with Aerobits products. Aerobits reserves the right to make changes, corrections, modifications or improvements to this document, and to products and services described herein at any time, without notice. All Aerobits products are sold pursuant to our own terms and conditions of sale. Buyers are solely responsible for the choice, selection and use of the Aerobits products and services described herein, and Aerobits assumes no liability whatsoever, related to the choice, selection or use of Aerobits products and services described herein. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services, it shall not be deemed a license granted by Aerobits for use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering use, in any manner whatsoever, of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN AEROBITS TERMS AND CONDITIONS OF SALE, AEROBITS DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO USE AND/OR SALE OF AEROBITS PRODUCTS INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHAN-TABILITY, FITNESS FOR A PAR- TICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGE- MENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT. UNLESS EXPRESSLY APPROVED IN WRITING BY AN AUTHORIZED AEROBITS REPRESENTATIVE, AEROBITS PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE.

Information in this document supersedes and replaces all previously supplied information.

© 2024 Aerobits - All rights reserved